

General

Additional Parts Required

This kit includes the URG supplied equipment only.

Proper installation of this kit requires the separate purchase of the following materials:

- 5/32 Allen wrench

Kit Contents: See Service Parts Table

Installation

1. Disengage the drive motor by grasping the bottom of the motor and pulling toward you. Pull down and slide motor to the left.
2. Grab the brass know on the release pin and slide the pin to the left; the module C frame is now loose.
3. Tilt the frame. Lift the motor and carefully guide it out.
4. Using a 5/32 Allen wrench, loosen the socket head cap screw on the right and left sides.
5. Slide the belt cover off and remove.
6. Loosen socket head cap screw in the middle to release tension on the belt.
7. Remove the belt and replace following the same orientation.
8. Tighten the belt tensioner by tightening the socket cap screw in the middle.
9. Install the belt cover and tighten screws.
10. Place the module C frame back in to the enclosure.
11. Engage release pin by sliding the pin to the right.
12. Engage the drive motor by sliding the motor to the right and pushing the motor back into place.

Service Parts Table

Kit	Installation Kit	Description (Quantity)	Part Number
		Motor Timing Belt for 3000N	URG-3N-TB